


Installation- and maintenance instruction  
**B30A**

## DESCRIPTION




## COMPONENTS

- |                         |                                |                    |
|-------------------------|--------------------------------|--------------------|
| 1. Shrouded disc        | 8. Reset button                | 14. Blast tube     |
| 2. Nozzle               | 9. Cover, inspection glass     | 15. Air adjustment |
| 3. Ignition electrodes  | 10. Fan wheel                  | 16. Air damper     |
| 4. Nozzle assembly      | 11. Motor                      | 17. Solenoid valve |
| 5. Ignition cable       | 12. Photo cell                 | 18. Air intake     |
| 6. Ignition transformer | 13. Nozzle assembly adjustment | 19. Pump           |
| 7. Control box          |                                |                    |

# TECHNICAL DATA

Type designation B 30A

## DIMENSIONS



Burner tube	Length of burner tube	Measure B
L	150	115
L Standard	222	187
L	350	315

## OUTPUT RANGE AND NOZZLES RECOMMENDED

Burner tube	Oil capacity kg/h	Output kW	Output Mcal/h	Recommended nozzle Angle	Danfoss	Monarch	Recommended Pump pressure
L	6,0-17,0	71-202	61-173	45° - 60°	S, B,	R, PLP	10-15bar

The net calorific value of 11,86 kWh/kg for light oil has been used.



## RECOMMENDED NOZZLE

Because of different boiler types existing on the market, with varying combustion chamber designs, it is not

possible to state a definite spray angle or spray pattern.

Note that the spray angle and the spray pattern change with the pump pressure.

## ELECTRODE ADJUSTMENT



# GENERAL INSTRUCTIONS

## GENERAL RULES

The installation of an oil burner should be carried out in accordance with local regulations. The installer of the burner must therefore be aware of all regulations relating to oil and combustion.

Only oil suitable for the burner should be used and then in combination with a suitable oil filter before the oil pump of the burner.

If the burner is replacing an existing burner make sure that the oil filter is replaced or cleaned. The installation must only be undertaken by experienced personnel. Care should be taken by the installer to ensure that no electrical cables or fuel/gas pipes are trapped or damaged during installation or service/maintenance.

## INSTALLATION INSTRUCTIONS

General installation instructions accompany the burner and should be left in a prominent place adjacent to the burner.

## ADJUSTMENT OF BURNER

The burner is from the factory pre-set to an average value that must then be adjusted to the boiler in question.

All burner adjustments must be made in accordance with boiler manufacturers instructions. These must include the checking of flue gas temperatures, average water temperature and CO<sub>2</sub> or O<sub>2</sub> concentration.

To adjust the combustion device, start by increasing the air volume and the nozzle assembly somewhat. When the burner starts it is burning with excess air and smoke number 0. Reduce the nozzle assembly adjustment until soot occurs, and then increase the adjustment to make the soot disappear again. Then the volume of air is reduced until soot occurs and increased again to reach a combustion free of soot.

By this procedure an optimum adjustment is obtained. If larger nozzles are used the preadjustment of both the air volume and the nozzle assembly must be increased.

A whistling sound may be heard which can be eliminated or reduced as follows: Increase the nozzle assembly adjustment somewhat. The CO<sub>2</sub>-content and consequently the air volume will then be reduced.

## CONDENSATION IN CHIMNEY

A modern burner works with less excess air and often also with smaller nozzles than older models.

This increases the efficiency but also the risk of condensation in the chimney. The risk increases if the area of the chimney flue is too large. The temperature of the flue gases should exceed 60°C measured 0,5 metres from the chimney top.

Measures to raise the temperature:  
Insulate the chimney in cold attics  
Install a tube in the chimney  
Install a draught regulator (dilutes the flue gases during operation and dries them up during standstill)  
Increase the oil quantity  
Raise the flue gas temperature by removing turbulators, if any, in the boiler.

## PUMP ADJUSTMENT

See separate description.

## MAINTENANCE

The boiler/burner should be examined regularly for any signs of malfunction or oil leakage.

## OIL SUPPLY

The oil line should be dimensioned in accordance with the pump manufacturer's instruction. In the suction line to the burner a filter should be mounted to prevent any particles in the oil from reaching the burner. If the installation consists of several burners each one should have its own suction line from the tank or a circulation system should be used.

The temperature in the oil line should be kept as constant as possible. Avoid exposing the line to excessive cold which may cause blockages of paraffin deposits.


The oil pipe and electric cable should be fitted so that the burner can be placed on the floor for inspection of the combustion device.

## ADJUSTMENT OF NOZZLE

### ASSEMBLY

Loosen the screw G and adjust the nozzle assembly by turning the screw F.

Max. capacity	- Front position
Medium capacity	- Middle position
Min. capacity	- Rear position



## AIR ADJUSTMENT


Loosen the stop screw B and turn the knob along the scale to the position wanted and tighten the screw. Check the air adjustment by making a flue gas analysis.

## MAINTENANCE


**Warning:** Before doing any service switch off power at the main switch and cut off the oil supply.

### SERVICE OF BURNER HEAD

Open the cover and disconnect the connecting pipes by loosening screw A.



1. Loosen or swing out the burner from the boiler.
2. Turn the blast tube to the left and withdraw it.



# ELECTRIC EQUIPMENT

## OIL BURNER CONTROL: LOA21.../LOA24...

### FUNCTION

#### 1. Switch on operating switch and twin thermostat

The burner motor starts, an ignition spark is formed, the prepurge goes on till the prepurge period expires and the solenoid valve opens (2).

#### 2. Solenoid valve opens

Oil mist is formed and ignited. The photocell indicates a flame.

#### (1) The ignition spark goes out 15 s. after flame indication (LOA24.171...).

#### (2) The ignition spark goes out 2 s. after flame indication when the ignition transformer is connected to terminal 7 (LOA24.173...).

#### 3. The safety time expires

- If no flame is established before this time limit the control cuts out.
- If for some reasons the flame disappears after this time limit, the burner will make an attempt to re-start.

#### 3-4. Operating position

If the burner operation is interrupted by means of the main switch or the thermostat, a new start takes place when the conditions in accordance with point 1 are fulfilled.

#### The oil burner control cuts out

A red lamp in the control is lit. Press the reset button and the burner re-starts.

#### Post-ignition

#### (2) If a post-ignition of 15 s. is wanted, move the ignition transformer from terminal 7 to terminal 6 (LOA24.173...).

### LIST OF COMPONENTS

A1	Oil burner control	R1	Photoresistor
A2	Twin thermostat	S3	Main switch
F1	Fuse, max. 10A	T1	Ignition transformer
H1	Alarm lamp	Y1	Solenoid valve
H2	Signal lamp (optional)	X1	Plug-in contact, burner
M1	Burner motor	X2	Plug-in contact, boiler
P1	Time meter (optional)		

Mains connection and fuses in accordance with local regulations.

### TECHNICAL DATA

Pre-ignition time:

13 s

Pre-purge time:

13 s

(1) Post-ignition time:

15 s

(2) Post-ignition time:

2 s

Safety lock-out time:

10 s

Reset time after lockout:

≈ 50 s

Reaction time on flame failure:

max. 1 s

Ambient temperature:

from - 20 to +60°C

Min. current with flame established:

65 μA

Max. photo current at start:


5 μA

Enclosure:


IP 40

(Under voltage proof only LOA24...)

### WIRING DIAGRAM



### OUTER ELECTRICAL CONNECTION



### CONTROL OF PHOTO CURRENT

Current through photo unit is measured with a d.c. ammeter (a moving coil instrument connected in series with the photo unit).


# INSTRUCTIONS PUMP TYPE SUNTEC AS47C

## TECHNICAL DATA

Viscosity range: 1-12 mm<sup>2</sup>/s  
 Pressure range: 7-12 bar  
 Oil temperature: max 60°C

## COMPONENTS

1. Pressure adjustment
2. By-pass plug
3. Nozzle outlet G 1/8"
4. Pressure gauge port G 1/8"
5. Vacuum gauge port G 1/8"
6. Return line G 1/4"  
and internal by-pass plug
7. Suction line G 1/4"
8. Pressure gauge port G 1/8"





## SUCTION LINE TABLES

The suction line tables consist of theoretically calculated values where the pipe dimensions and oil velocity have been matched so that turbulences will not occur. Such turbulences will result in increased pressure losses and in acoustic noise in the pipe system. In addition to drawn copper piping a pipe system usually comprises 4 elbows, a non-return valve, a cut-off valve and an external oil filter.

The sum of these individual resistances is so insignificant that they can be disregarded. The tables do not include any lengths exceeding 100 m as experience shows that longer lengths are not needed.

The tables apply to a standard fuel oil of normal commercial quality according to current standards. On commissioning with an empty tube system the oil pump should not be run without oil for more than 5 min. (a condition is that the pump is being lubricated during operation).

The tables state the total suction line length in metres at a nozzle capacity of 2,1 kg/h. Max. permissible pressure at the suction and pressure side is 2,0 bar. For two-pipe system  $Q_{max}$  46 l/h pump capacity at 0 bar.

	
1-pipe system	1-pipe system
Height H      Pipe diameter ø4 mm	Height H      Pipe diameter ø4 mm
m            m	m            m
4,0        100	
3,0        100	
2,0        100	
1,0        91	
0,5        82	
0,0        74	
With an underlying tank a 1-pipe-system is not recommended	
Two-pipe system	Two-pipe system
Height H      Pipe diameter ø6 mm	Height H      Pipe diameter ø6 mm
m            m	m            m
4,0        29	0,0        14
3,0        25	-0,5        12
2,0        22	-1,0        10
1,0        18	-2,0        7
0,5        16	-3,0        3
0,0        14	-4,0        0

## APPLICATIONS FOR SUNTEC AS47C

- Light fuel oil and kerosine.
- Nozzle flow up to 46 l/h (approx. 395 000 kcal/h - 470 kW).
- One or two-pipe system.

## PUMP OPERATING PRINCIPLE

The SUNTEC AS oil pump has a built in solenoid valve which controls the regulator cut-off valve giving fast cut-off and cut-on function independent of the rotational speed.

The gear-set draws oil from the tank through the built-in filter and transfers it to the valve that regulates the oil pressure to the nozzle line.


All oil which does not go through the nozzle line will be dumped through the valve back to the return line or, if it is a one-pipe installation, back to the suction port in the gear-set.

### -TWO-PIPE OPERATION

When the solenoid valve is non-activated, the by-pass channel between the pressure and return sides of the valve is open.

No pressure will then be built up to open the valve. It does not matter which speed the gear set has.

When the solenoid is activated, this by-pass channel will be closed and because of the full speed of the gear-set, the pressure necessary to open the valve will be built up very rapidly which gives a very sharp cut-on function.



### -ONE-PIPE OPERATION

Bleeding on one-pipe is not automatic, and a pressure port must be opened to bleed the system.

### CUT-OFF

When the burner stops, the solenoid opens the by-pass at the same moment which drains all the oil down to the return and the nozzle valve closes immediately. This gives a very sharp cut-off function.

The cut-on and off can be regulated regardless of motor speed and has an extremely fast response.

When the solenoid is non activated, the torque requirement is low up to full motor speed.


Shaft rotation and nozzle location  
C: Anti-clock. rotation/  
Left hand nozzle (seen from  
Shaft end)

Gear set capacity  
(see pump capacity curves)


AS:Solenoid valve  
with cut-off

AS 47 C

## EXCHANGE OF FILTER



## MOUNTING/DISMOUNTING RETURN PLUG



## NOZZLE TABLE

Gph	8				9				10				11				12				13				14				Pump pressure bar	
	kg/h	kW	Mcal/h	kg/h	kW	Mcal/h																								
0,40	1,33	16	13	1,41	17	14	1,49	18	15	1,56	18	16	1,63	19	17	1,70	20	17	1,76	21	18	1,82	21	18	1,82	21	18			
0,50	1,66	20	17	1,76	21	18	1,86	22	19	1,95	23	20	2,04	24	21	2,12	25	22	2,20	26	22	2,28	27	23	2,28	27	23			
0,60	2,00	24	20	2,12	25	22	2,23	26	23	2,34	28	24	2,45	29	25	2,55	30	26	2,64	31	27	2,73	32	28	2,73	32	28			
0,65	2,16	26	22	2,29	27	23	2,42	29	25	2,54	30	26	2,65	31	27	2,75	33	28	2,86	34	29	2,96	35	30	2,96	35	30			
0,75	2,49	29	25	2,65	31	27	2,79	33	28	2,93	35	30	3,08	36	31	3,18	38	32	3,30	39	34	3,42	40	35	3,42	40	35			
0,85	2,83	33	29	3,53	42	36	3,72	44	38	3,90	46	40	4,08	48	42	4,24	50	43	4,40	52	45	4,56	54	46	4,56	54	46			
1,00	3,33	39	34	3,88	46	39	4,09	48	42	4,29	51	44	4,48	53	46	4,67	55	48	4,84	57	49	5,01	59	51	5,01	59	51			
1,10	3,66	43	37	4,76	56	48	5,02	59	51	5,27	62	54	5,50	65	56	5,73	68	58	5,95	70	61	6,15	73	63	6,15	73	63			
1,20	3,99	47	41	4,24	50	43	4,47	53	46	4,68	55	48	4,89	58	50	5,10	60	52	5,30	63	54	5,51	65	56	5,51	65	56			
1,25	4,16	49	42	4,40	52	45	4,65	55	47	4,88	58	50	5,10	60	52	5,30	63	54	5,51	65	56	5,70	68	58	5,70	68	58			
1,35	4,49	53	46	4,76	56	48	5,02	59	51	5,27	62	54	5,50	65	56	5,73	68	58	5,95	70	61	6,15	73	63	6,15	73	63			
1,50	4,98	59	51	5,29	63	54	5,58	66	57	5,85	69	60	6,11	72	62	6,36	75	65	6,60	78	67	6,83	81	70	6,83	81	70			
1,65	5,49	65	56	5,82	69	59	6,14	73	63	6,44	76	66	6,73	80	69	7,00	83	71	7,27	86	74	7,52	89	77	7,52	89	77			
1,75	5,82	69	59	6,18	73	63	6,51	77	66	6,83	81	70	7,14	85	73	7,42	88	76	7,71	91	79	7,97	94	81	7,97	94	81			
2,00	6,65	79	68	7,06	84	72	7,45	88	76	7,81	93	80	8,18	97	83	8,49	101	86	8,81	104	90	9,12	108	93	9,12	108	93			
2,25	7,49	89	76	7,94	94	81	8,38	99	85	8,78	104	89	9,18	109	94	9,55	113	97	9,91	117	101	10,26	122	105	10,26	122	105			
2,50	8,32	99	85	8,82	105	90	9,31	110	95	9,76	116	99	10,19	121	104	10,61	126	108	11,01	130	112	11,39	135	116	11,39	135	116			
2,75	9,15	108	93	9,71	115	99	10,24	121	104	10,73	127	109	11,21	133	114	11,67	138	119	12,11	144	123	12,53	148	128	12,53	148	128			
3,00	9,98	118	102	10,59	126	108	11,16	132	114	11,71	139	119	12,23	145	125	12,73	151	130	13,21	157	135	13,67	162	139	13,67	162	139			
3,50	11,65	138	119	12,35	146	126	13,03	154	133	13,66	162	139	14,27	169	145	14,85	176	151	15,42	183	157	15,95	189	163	15,95	189	163			
4,00	13,31	158	136	14,12	167	144	14,89	176	152	15,62	185	159	16,31	193	166	16,97	201	173	17,62	209	180	18,23	216	186	18,23	216	186			
4,50	14,97	177	153	15,88	188	162	16,75	198	171	17,57	208	179	18,35	217	187	19,10	226	195	19,82	235	202	20,51	243	209	20,51	243	209			
5,00	16,64	197	170	17,65	209	180	18,62	221	190	19,52	231	199	20,39	242	208	21,22	251	216	22,03	261	225	22,79	270	232	22,79	270	232			
5,50	18,30	217	187	19,42	230	198	20,48	243	209	21,47	255	219	22,43	266	229	23,34	277	238	24,23	287	247	25,07	297	256	25,07	297	256			
6,00	19,97	237	204	21,18	251	216	22,34	265	228	23,42	278	239	24,47	290	249	25,46	302	260	26,43	313	269	27,49	326	280	27,49	326	280			
6,50	21,63	256	220	22,94	272	234	24,20	287	247	25,37	301	259	26,51	314	270	27,58	327	281	28,63	339	292	29,63	351	302	29,63	351	302			
7,00	23,29	276	237	24,71	293	252	26,06	309	266	27,33	324	279	28,55	338	291	29,70	352	303	30,84	366	314	31,91	378	325	31,91	378	325			
7,50	24,96	296	254	26,47	314	270	27,92	331	285	29,28	347	298	30,59	363	312	31,83	377	324	33,04	392	337	34,19	405	349	34,19	405	349			
8,00	26,62	316	271	28,24	335	288	29,79	353	304	31,23	370	318	32,63	387	333	33,95	403	346	35,25	418	359	36,47	432	372	36,47	432	372			
8,50	28,28	335	288	30,00	356	306	31,65	375	323	33,18	393	338	34,66	411	353	36,07	428	368	37,45	444	382	38,74	459	395	38,74	459	395			
9,00	29,95	355	305	31,77	377	324	33,59	398	342	35,14	417	358	36,71	435	374	38,19	453	389	39,65	470	404	41,02	486	418	41,02	486	418			

The table applies to oil with a viscosity of 4.4 mm<sup>2</sup>/s (cSt) with density 830 kg/m<sup>3</sup>.

### BURNER WITH PREHEATER

Consider that on preheating the oil quantity is reduced by 5-20% depending on:

- Rise in temperature at the nozzle
- Design of nozzle
- Capacity (high capacity - small difference)

# FAULT LOCATION

## BURNER FAILS TO START

Situation	Possible causes	Remedies
Motor runs	Flame instability	
Burner pre-purges	Incorrect head settings Low oil pressure Excess air	Check nozzle to burner head dimension and electrode position Check oil pressure Adjust air damper
Flame occurs		
Burner locks out	Photocell not seeing light Photocell failed	Check that photocell is clean and unobstructed Confirm with new photocell
Motor runs	Control faulty	Confirm with new control. (NB. it is advisable to change the photocell if also changing control)
Burner pre-purges	False light	Check that photocell is not seeing ambient light
No flame occurs	No spark	Check that H.T. leads are sound and are not arcing other than at electrode gap
Burner locks out	No oil	Check oil supply to burner - check that pump is not airlocked Check operation of magnetic valve

## BURNER FAILS TO START AFTER NORMAL OPERATION

Burner fails to start	Fuse has blown	Check or replace fuse if necessary. Check reason for failure
	Appliance thermostat has not reset	Adjust thermostat
Lamp not lit	Appliance overheat device has operated	Reset overheat device. Find reason for its operation and rectify
	Control relay or photocell defective	Check by replacement
Motor runs	No oil being delivered	Check that tank, oil lines, fire valve, pump and nozzle are all in good order
Burner runs to lockout	Excessive flue draught is preventing flame establishment	Rectify condition
	No spark	Check ignition transformer. Check electrode gap and porcelain

## DELAYED IGNITION, BURNERS STARTS VIOLENTLY

Burner pulsates on start-up only with hot flue	Excessive draught	Adjust the burner
Burner pulsates on start-up	Nozzle partly blocked	Replace nozzle
	Oil pressure too low	Check and adjust
	Flue blocked or damaged	Check and rectify
	Fan slipping on shaft	Check and retighten
	Pump coupling loose or worn	Check and replace
Burner starts violently	Delayed ignition	Check the electrode adjustment, see diagram Check electrodes for damage Check H.T. leads for damage and disconnection

# DECLARATION OF CONFORMITY

Manufacturer: Enertech AB, Bentone Division  
Street address: Näsvägen

Address: SE-341 34 Ljungby  
P.O. Box 309  
SE-341 26 Ljungby  
Sweden

Product: Oil burner

Type: BF1, B 1, B 2, B 9, B 10, B 11, B 20, B 30, B 40, B 45,  
B 50, B 55, B 60, B 65, B 70, B 80, ST 97, ST 108,  
ST 120, ST133, ST 146

Certifikat TÜV Süddeutschland

Certifikat Nr Burner

XXXXXXX BF1

011110535004 B1

0207110535005 B2

021198p15001 ST97, ST108, ST120, ST133, ST146

02119815002 B9, B10, B11

02119815003 B20, B30, B40, B45

02119815004 B50, B60, B70, B80

040588622001 B55

040588622002 B65

Enertech AB declares under sole responsibility that the above mentioned product is in conformity with the following standards or other normative documents.

Document: EN 267

and follows the provisions of applicable parts in the following EU Directives:

89/336/EEC Electromagnetic compatibility

73/23/EEC Low-voltage directive

89/392/EEC Machinery directive

92/42/EEC Efficiency directive

In that the burner conforms to the above mentioned standards it is awarded the CE mark.

Enertech AB, Bentone Division is quality certified according to SS-EN ISO 9001:2000

Ljungby 080115

**ENERTECH AB**  
Sven-Olov Lövgren

